

Get and activate your license key



See page 1




Siehe Seite 5

Notes applicable for the software:

- stute.x1D Loudspeaker Designer V1.7 or above
- stute.x1A Audio Analyzer V1.7 or above
- DCX.Server V1.1 or above

Note: A license can activated 3 times.

Note: The software products are available as a download here, <https://www.stute-engineering.de/index.php/download>. The software work as a trial version without a valid license key.



Software License Key

Step 1: Order a software license: [Link to our web shop...](#)

Step 2: Request a software license key.
Your installation key: 80827[REDACTED]
Note: Copy with a double-click the key into the clipboard.

Option A) Via email request:

Option B) Via request form: [Link to the request form...](#)

Note: You receive your license key via email.

Step 3: Enter and check the license key.
Input the key from the email

Note: Press finally "Check the license". A green screen background indicates a correct key.

Get and activate a software license

- Install and open your software product, e.g. stute.x1A
- During the start procedure a software activation screen is displayed

Step 1: Order a software license

Order a license from our web store, if not already done. Store: <https://www.stute-engineering.de/shop/>

Step 2: Request a software license key


Option A) Via email request

- Enter your **invoice number** here
- Press the button "Create an email..."
- An Email is created within your default Email program
 - Transmit the Email to us (correct address is per default entered)

➔ You get an email with the software license key within 1-2 business days.

Option B) Request via web form

- Double-click at the installation key (action copied the key into the clipboard)



- Click at the displayed Link "Link to the request form..."
- Select a software product
- Paste the installation key into the text field and enter your invoice number
- Enter your name and email address

Get your software license key:

For your request we need the **invoice number** to the ordered product and the **installation key**. Please enter the data in the fields below and transmit your request.

Select a software product *

Your invoice number *

Your installation key *

Your name *

Your email address *

I agree with the storage of the entered data / Ich stimme der Speicherung der eingegebenen Daten zu

Safety I'm not a robot


- Transmit the form
- Note: Access to the form via our home page, menu Contact/Software license key

➔ You get an email with the software license key within 1-2 business days.

Step 3: Activate your software license

Pre-condition: You have already received the license key via email.

- Enter the key in the textbox “**Enter your SW key here...**”



- Press the button “**Check the license**”
- **The background color of the screen changes to green, if the key is valid**
- Press the “Close” button

Your software license is activated and the DEMO limitations are removed.

Lizenz-Key erhalten und aktivieren



Anwendbar für die Software


- stute.x1D Loudspeaker Designer V1.7 oder höher
- stute.x1A Audio Analyzer V1.7 oder höher
- DCX.Server V1.1 oder höher

Hinweis: Eine Lizenz kann bis zu 3-mal aktiviert werden.

Hinweis: Die Software erhalten Sie hier als Download, <https://www.stute-engineering.de/index.php/download>. Ohne eine gültige Software-Lizenz können Sie die Software als eingeschränkte Demo-Version nutzen.

Software Lizenz erhalten und aktivieren

- Installiere und öffnen das Softwareprodukt, z.B. stute.x1A
- Während der Startprozedur der Software wird der Lizenz-Key Bildschirm angezeigt



Step 1: Software Lizenz kaufen

Kaufen Sie eine Software Lizenz über unseren Online-Shop: <https://www.stute-engineering.de/shop/>, falls nicht schon erfolgt.

Step 2: Lizenz-Schlüssel anfordern

Option A) Per Email

- Geben Sie die Ihre Rechnungsnummer hier ein
- Betätigen Sie die Taste "Create an email..."
- Eine Email mit den benötigten Daten wird in Ihrem Standard-Email Programm erstellt.
- Senden Sie die Email an die voreingestellte Email-Adresse

➔ Sie erhalten den Lizenz-Schlüssel innerhalb 1-2 Arbeitstagen

Option B) Anfrage via Online-Formular

- Kopieren Sie den Installations-Key in die Windows Zwischenablage mit einem Maus-Doppelklick auf den Key

- Öffnen Sie das Online-Formular via a Klick auf den Link "Link to the request form..."
- Wählen Sie ein Softwareprodukt
- Kopieren Sie den Installations-Key in das Feld "Your installation key" und geben Sie Ihre Rechnungsnummer ein "Your invoice number"
- Geben Sie Email Adresse und Ihren Namen an

Get your software license key:

For your request we need the **invoice number** to the ordered product and the **installation key**. Please enter the data in the fields below and transmit your request.

Select a software product *


Your invoice number *

Your installation key *

Your name *

Your email address *

I agree with the storage of the entered data / Ich stimme der Speicherung der eingegebenen Daten zu

Safety I'm not a robot 


- Senden Sie das Formular ab
- Hinweis: Zugriff auf das Formular über unsere Homepage: Contact/Software license key

➔ Sie erhalten den Lizenz-Schlüssel innerhalb 1-2 Arbeitstagen

Step 3: Aktivieren Sie Ihre Software Lizenz

Voraussetzung für den letzten Schritt: Der Lizenz-Schlüssel wurde Ihnen per E-Mail zugesendet.

- Geben Sie den Lizenz Schlüssel in das Feld **"Enter your SW key here..."**



- Betätigen Sie die Taste **"Check the license"**
- **Der Fensterhintergrund wechselt auf Grün, wenn der Key akzeptiert wurde**
- Betätigen Sie die Taste "Close" um das Fenster zu schließen

Ihre Software ist nun aktiviert und die DEMO Beschränkungen wurden aufgehoben